

Timeclock Guide – ATS Wi-Fi Adapter Installation Guide

Overview:

- Installing the ATS Wi-Fi Adapter
- Configure the ATS 700 timeclock to connect to your Wi-Fi network

Installing the ATS Wi-Fi Adapter


- 1) Power the timeclock **off**
- 2) **Unlock** the ATS 700 timeclock
- 3) **Insert** the Wi-Fi adapter into the primary USB port.




- 4) Power the timeclock back **on**.

Configure the ATS 700 Timeclock for Wi-Fi

- 1) On the timeclock, tap the **Wrench Icon** 
- 2) Enter the Setup Password (Common passwords: 1234 or clock's serial number), Tap **Enter**



- 3) Tap **Setup**



Timeclock Guide – ATS Wi-Fi Adapter Installation Guide

- 4) Enter Setup Password, tap **Enter Setup**


- 5) **Check** the box next to Wi-Fi, tap **Configure**

- 6) Expand the drop-down box next to **SSID**, tap your Network Name

Note: If your network does not appear > Enter the network name in the Hidden SSID field. This field is case sensitive.


Timeclock Guide – ATS Wi-Fi Adapter Installation Guide

- 7) In the **Key** field, enter your Wi-Fi password




The screenshot shows the 'WiFi Configuration' screen with tabs for Interfaces, Options, Administration, and Info. The 'Options' tab is active. Fields include DHCP (checked), IP, Mask, Gateway, DNS (8.8.8.8), SSID (Konosuba), and a Key field which is highlighted in yellow. A Hidden SSID field is also present. At the bottom are buttons for Save, Cancel, and Reboot.

- 8) Tap **Save** and wait 15 seconds



This screenshot is identical to the previous one, but the 'Save' button at the bottom is highlighted with a red border.

- 9) A **status** will appear upon saving.



The screenshot shows the 'WiFi Configuration' screen after saving. A new field 'Status: connected (Konosuba - 100%)' has appeared next to the Key field and is highlighted with a red border. The other fields and buttons remain the same.

Connected: We highly recommend at least 70% connectivity. If your percentage is lower, we recommend moving the clock closer to the router.

Disconnected: Verify your Wi-Fi network information. If the network information is correct, reach out to our support team for further assistance. In some cases, we may ask for your IT or internet service provider to be involved to verify network settings.